

DOOR SILL PLATES (REAR)

18+ WRANGLER JL (4-DOOR)

20+ GLADIATOR JT

D-JP-180014-STR4



TOOLS REQUIRED

SKILL LEVEL

TIME REQUIRED

- Novice
- 1 (you)

Little skill level required, you can easily install it by yourself.

- .5 Hour

Time to install this should only take about half an hour.

WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit – Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner’s manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.
Customer Service: 855-680-9595

DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

- Always wear eye protection when operating power tools

Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover



INSTALLATION MANUAL

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from. Extra hardware may be included with the product.



STEP 1 | Peel back the plastic on the DV8 door sill to reveal the adhesive.



STEP 2 | Install the sill by pressing it firmly into place.

Be sure to place it carefully and ensure it is even and centered before pressing firmly.



INSTALLATION MANUAL

STEP 3 | Congrats! You are finished with the install of the DV8 Rear Passenger Door Sill!

