

ELITE SERIES D-RINGS

UNSK-01 (BL,RD,GR)



TOOLS REQUIRED

- 3/8" Ratchet / Impact

SKILL LEVEL

- Easy
- 1 (you) person

Little skill level required, you can easily install it by yourself.

TIME REQUIRED

- 3 minutes per side.

Time to install this should only take about 6min total.

WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit – Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.
Customer Service: 855-680-9595

DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

• Always wear eye protection when operating power tools

Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover

INSTALLATION MANUAL

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from. Extra hardware may be included with the product.

HARDWARE INCLUDED

- (4) 1/8" Isolators
- (4) 3/16" Isolators
- (2) 7/16" Pin



STEP 1 | Unscrew the pin from the shackle and remove the four isolators from the pin. You may be able to do this by hand, if not use your 3/8" tool.



STEP 2 | Identify what isolators will be used by holding up the shackle and fitting the isolators between the outside of your bumper mount and inside of the shackle.

NOTE: Different variations of isolators will be used based on the thickness of your bumper D-Ring mount. In our case, our 1" thick D-Ring mount accepted both 1/8" isolators.



INSTALLATION MANUAL

STEP 3 | Once isolators have been selected, hold up the shackle and isolators, and feed the pin through the shackle.

Once it bottoms out, begin screwing it into the shackle.



STEP 4 | Using a 3/8" ratchet/chuck, begin to tighten the pin into the shackle until secure. The pin should be tight enough that the pin cannot be loosened by hand.

NOTE: The opening in the pin may have some slack around a 3/8" ratchet/chuck since it is also designed to be used with factory tire changing posts (not all applications will work).



STEP 5 | Double check both pins are secure, and you are ready to put your new Elite Series D-Ring to the test!

