

JL REAR INNER FENDERS

2018 + JEEP JL

INFEND-06RB



TOOLS REQUIRED

- #3 & #4 Allen head Tool
- 8mm socket
- 10mm Wrench
- Trim clip tool

SKILL LEVEL

- Novice/Intermediate
- 1 (you)

Little skill level required, you can easily install it by yourself.

TIME REQUIRED

- 2 Hours

Time to install this should only take about two hours

WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit – Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.
Customer Service: 855-680-9595

DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

- Always wear eye protection when operating power tools

Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover




INSTALLATION MANUAL

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from. Extra hardware may be included with the product.

HARDWARE INCLUDED

- | | |
|------------------------------|------------------------------|
| (8) M6x20mm Allen Head Bolts | (4) M5x30mm Allen Head Bolts |
| (8) M6 Nylon Lock Nuts | (12) M5 Flat Washers |
| (22) M6 Flat Washers | (4) Christmas Tree Push Pins |
| (6) M6x12mm Allen Head Bolts | |



STEP 1 | Use a trim clip tool to separate the inner fender from the fender.



INSTALLATION MANUAL

STEP 2 | Using the trim clip tool, remove the (8) factory push pins.

With a firm grip, pull the factory inner fender down and out of the wheel well.



INSTALLATION MANUAL

STEP 3 | Use a 8mm socket to remove the (3) bolts that secure the lower inner fender on each side.




INSTALLATION MANUAL

STEP 4 | Lay the DV8 inner fenders on a covered work bench.


Place the upper panel behind the lower panel with mesh. Secure the upper and lower panels together using the provided M6x12mm Allen head bolts and a #4 Allen tool.

Use (1) M6 flat washer per M6x12mm bolt.



STEP 5 | Secure the side of upper panel to the lower panel using the provided M6x20mm Allen head bolts, M6 Nylon lock nuts, #4 Allen tool and a 10mm wrench.

Use 2 M6 flat washers per M6 bolt. (Lock nut side and Allen head side)



INSTALLATION MANUAL



STEP 6 | Place the DV8 inner fender assembly into the wheel well, behind the fender panel.

Secure the inner fender to the fender panel using the provided M5x30mm Allen head bolts and the pre-installed M5 nuts.



INSTALLATION MANUAL

STEP 7 | Press the inner fender against the back of the wheel well, use the provided Christmas tree push pin to secure the inner fender to the wheel well.

Double check that all hardware is secured.

Note: If you do not wish to use provided push pins, DV8 also provides additional M5 Nutserts and M5 Allen head bolts/M5 washers to use in place of the push pin.



STEP 8 | Congratulations, you have finished the install of the DV8 Offroad JL Rear Inner Fenders.

